



> Close

> Print

WG794E Top Cover



	* Part No	Description	Qty
5	50022495	Self Tapping Screw	14
14	50022517	Self Tapping Screw	22
21	50024661	Magnet	1
22	50024662	Film I	1
23	50024663	Film II	1
24	50024671	Button	1
25	50024672	Spring Plate II	1
26	50020159	Screw	2
27	50000659	Compression spring	2
28	50024673	Handle	1
29	50024674	Film III	1
30	50024675	Cutting Pin	1
31	50022502	Bolt	2
32	50020336	O Ring	2
33	50024676	Top Cover I	1
34	50024677	Press Plate II	1
36	50022506	Nut	2
37	50000976	Washer	3
38	50024678	Seal Gasket	1
39	50024679	Button Board	1
40	50024680	Inspect Window	1
41	50024681	Protect Plate	1
42	50024682	Spring Plate I	2
43	50024683	E Ring	1
44	50024684	Rotating Block	1
45	50022546	Position Piece	1
46	50024685	Pin	1
47	50024686	Monitor Board	1
48	50019775	Press Plate	2
49	50024687	Fixing Block	1
50	50024689	Scale Plate	1
51	50024690	Depth Adjustment Knob	1
64	50024698	Separated Plate	1
71	50022512	Washer	1
82	50024703	Display Board	1
100	50003050	Washer	1
203	50024688	Depth Adjustment Knob	1